

Sensor made of Graphite

General features

- Easy to use
- Low cost
- Small size
- Short response time
- Android application
- o Bluetooth connection
- Small sensitivity
- Two differents samples



Figure 1: Sensor made of graphite

Description

This overall sensor constitued of an PCB shield and a graphite sensor, and developed at the Physical Departement of INSA Toulouse, is for measuring resistor and tension of the graphite sample. The PCB shield was made for being connected on an Arduino Uno card. So, the PCB is composed by an Bluetooth module (for permissing bluetooth connection with an Android mobile), an OLED screen (for displaying values measured), a rotatory encoder (for changing the measure display) and a transimpedance circuit with a and low-pass filtering to extract useful information from the strain sensor. Also, we have made two differents graphite sensors who change with the graphite concentration (ascending order): HB, B.

With the Android application, you can connect the PCB to your phone and draw the resistor evolution of your sample on it.



Electrical/Schematical Description




Figure 2: PCB shield KiCad





Figure 3: PCB shield Kicad (3D view)



Figure 3: Global circuit





Bluetooth module HC05:

PIN NUMBER	USAGE
1	+5V
2	GND
3	RX (Receive)
4	TX (Transmit)

OLED 0.91:

1	GND
2	+5V
3	SCK (Serial Clock)
4	SDA (Serial Data)

Rotatory Encoder KY-040:

1	CLK
2	DATA
3	SWITCH
4	+5V
5	GND

Specifications

Туре	Nanoparticle based sensor
Materials	Graphite (HB,B)
Sensor type	Passive sensor
Resistor measurement	Resistive measure
Tension measurement	Resistive measure
Mountig	Overall Sensor (PCB Shield + Sensor + Android application + Arduino Uno required) + toothless alligator clips
Time Response	Between 0.5s et 1s
PCB Length	66mm
PCB Width	53mm
PCB Height (min and max)	1.5mm
PCB Mass	29g
PIN Diameter	0.8 mm



Standard use conditions

FACTOR	TYPICAL VALUE
Temperature	20°C ± 5°C
Humidity	40 to 60%
Bluetooth distance	20m max
Nominal Area	0*
Deterator Area	Infini*2
Destruction Area	Infini* ³

- *: A slight deformation changes the basic resistance of the sensor, so there is no Nominal Area.
- *2: When the sensor starts to be deformed, we are in the zone of deterioration, it is irreversible (single use).
- *3: The sensor is "destroyed" once folded (single use).

Test graphs for different graphite concentration on the sample

Variation de resistance relative en fonction de la deformation : HB et B

